

Clear Water Concepts

6056 E. Baseline Rd.
Suite 107
Mesa AZ 85206
480.373.9949

Olympus / Sanitech Softener Start-Up Instruction

- 1) Program Current Time – press set time button the hour will flash set correct hour (make sure AM/PM is correct). Press Next button minutes will flash. Set minutes to correct time of day. Press Next button until time of day is static (not blinking)
- 2) Set Water Hardness – From Clock screen, press Next and Arrow Up button together at same time and release. Hardness will display, set hardness(UP/Down Arrows) to your current water hardness (city water). I usually recommend setting 1 or 2 grains higher for fluctuations. Once hardness is set press Next button, days to regen displayed, set to 28. Press Next Button, regen time displays 2:00am do not change unless you want to regenerate for another time. Press Next until the time screen is displayed.

Open the inlet side of by-pass halfway. Leave the Outlet side closed. Immediately press and HOLD Regen button for approx. 3 seconds and release. You will hear the motor start to run. This 1st cycle is the backwash cycle. It will run for approximately 8 minutes. You will hear air/water escaping down the drain line. Open the Inlet valve fully after 2-3 minutes. After the backwash cycle has finished, the valve will go into the brine rinse cycle (60 minutes), press Regen button to forego this cycle it is not necessary as the resin is pre charged, and there is no brine in the salt tank. Let the system continue through 2nd backwash/rinse, and Fill cycles. This will take approx. 20-25 minutes. Open the Outlet side on the bypass valve.

Do Not fill Salt tank more than approx.1/2 way full of salt.